



TECHNICAL DATA

OUTPUT MAX	500 W	
SPEED	9,500 R.P.M.	
VOLTAGE	115 V or 230 V	
TOTAL LENGTH	715 mm / 28"	
MIXER TOOL LENGTH	410 mm / 16"	
DIAMETER	110 mm / 4.3"	
ACTUAL WEIGHT -	3.4 kg / 7.5 lbs-	
SHIPPING WEIGHT	3.8 kg / 8.4 lbs	
SHAFT	NON DETACHABLE	

EXAMPLE A CONTRACT OF THE SECOND SEC

- Powerful, sturdy
- Easy to use
- Non detachable mixer tool: ensures durability of the mixer
- Safety button
- Switch
- Double insulation
- Stainless steel mixer tube and guard for easy cleaning and perfect hygiene
- Titanium-plated blade easy to remove
- Variable speed optional

MAINTENANCE

Put the tube with the blade protector in clear water and start the machine for 3 seconds or more to clean the inside of the blade protector.

Clean the outside of the tube and the blade protector by passing it under the faucet.

Wash the motor block with a sponge or with a slightly damp cloth.

Never clean this machine with a water jet spray.

USE

It allows to mix, directly in the pots, many applications including: fish soups, panades (thick soup reduced to puree), salad dressings, pancakes paste, gravies, sauces, mayonnaise, puree of vegetables lightly pulverized, porridge, raw carrots puree, fruits cream ...

Capacity: 40 to 100 L / 10 to 25 gal.

518 rue Léo Baekeland - BP57 - 85290 Mortagne / Sèvre Tèl : +33 (0)2 51 63 02 72 - Fax : +33 (0)2 51 63 02 73 E-mail : contact@dynamicmixers.com

Dynamic

TECHNICAL SHEET

MX 91 MIXER

Motor brushes (2) 0504 Ball bearing 0601 Waterproof seal 0607 Squeezing washer 0726 Lock button return spring 0767 Safety button return spring 0768 Wall bracket 0881 Long wall bracket 0881 Strain relief 115 V 0950.1 Switch (230 V / 115 V) 0965 Capacitor 0972 Capacitor + filter 0972 Warning label 1017 Dynamic label 1027 Label W/ serial number 230 V 1028 Label W/ serial number 115 V 1029 bearing holder + seal 1186 Emulsifying blade 7910 Lower bearing assembly 7916 Cutter blade 7917 Fan 79350 Brace screws (4) 8317 Upper half handle (button side) 9002 Safety switch 9005 Locking switch 9007 Rotor 115 V 9008 Power cord 230 V 9	Parts list	Code
Ball bearing 0601 Waterproof seal 0607 Squeezing washer 0767 Lock button return spring 0768 Wall bracket 0881 Long wall bracket 0881 Strain relief 230 V 0950. Strain relief 115 V 0950. Switch (230 V / 115 V) 0950. Capacitor 0972. Capacitor 0972. Qapacitor + filter 0972.1 Warning label 1017 Dynamic label 1027 Label w/ serial number 230 V 1028 Label w/ serial number 230 V 1028 Label w/ serial number 230 V 1029 bearing holder + seal 1186 Emulisitying blade 7910 Lower bearing assembly 7916 Cutter blade 7917 Fan 7933 Lower bearing screws (3) 7950 Brace screws (4) 9007 Rotor 115 V 9008.11 Rotor 230 V 90014 Motor housing brush holder	Motor brushes (2)	0504
Waterproof seal 0607 Squeezing washer 0726 Lock button return spring 0768 Safety button return spring 0768 Wall bracket 0881 Long wall bracket 0881 Strain relief 135 V 0950 Strain relief 115 V 0950 Switch (230 V / 115 V) 09650 Capacitor 0972 Capacitor + filter 0972.1 Warning label 1017 Dynamic label 1027 Label w/ serial number 230 V 1028 Label w/ serial number 15 V 1029 bearing holder + seal 1186 Emulsifying blade 7910 Lower bearing assembly 7916 Cutter blade 7917 Fan 7933 Lower bearing screws (3) 7950 Brace screws (4) 8317 Upper half handle (button side) 9002 Safety switch 9007 Rotor 115 V 9008.12 Plug 9009 Control lever <t< td=""><td></td><td></td></t<>		
Squeezing washer 0726 Lock button return spring 0767 Safety button return spring 0768 Wall bracket 0881 Long wall bracket 0881 Strain relief 230 V 0950 Strain relief 115 V 0950.1 Switch (230 V / 115 V) 0965 Capacitor 0972.1 Warning label 1017 Dynamic label 1027 Label w/ serial number 230 V 1028 Label w/ serial number 115 V 1029 bearing holder + seal 1186 Emulsifying blade 7910 Lower bearing assembly 7916 Cutter blade 7917 Fan 7933 Lower bearing screws (3) 7950 Brace screws (4) 9002 Safety switch 9000 Locking switch 9009 Control 15 V 9008.12 Plug 9001 Power cord 230 V 9011 Handle screws (2) 9023 Ball bearing ring 9025 <td></td> <td>0607</td>		0607
Lock button return spring 0767 Safety button return spring 0768 Wall bracket 0881.L Long wall bracket 0881.L Strain relief 115 V 0950.1 Switch (230 V / 115 V) 0965 Capacitor 0972 Capacitor + filter 0972.1 Dynamic label 1017 Dynamic label 1027 Label w/ serial number 230 V 1028 Label w/ serial number 115 V 1029 bearing holder + seal 1186 Emulsifying blade 7910 Lower bearing assembly 7916 Cutter blade 7917 Fan 7933 Lower bearing screws (3) 7950 Brace screws (4) 9002 Safety switch 9002 Locking switch 9001 Power cord 115 V 9008.11 Rotor 120 V 9011 Pluq 9001 Power cord 230 V 9012 Stator screws (2) 9023 Ball bearing ring 9025 </td <td></td> <td>0726</td>		0726
Safety button return spring 0768 Wall bracket 0881 Long wall bracket 0881 Strain relief 230 V 0950.1 Switch (230 V / 115 V) 0950.1 Switch (230 V / 115 V) 0950.1 Switch (230 V / 115 V) 0972 Capacitor 0972 Capacitor + filter 0972.1 Warning label 1017 Dynamic label 1027 Label W/ serial number 230 V 1028 Label W/ serial number 230 V 1029 bearing holder + seal 1186 Emulsifying blade 7910 Lower bearing assembly 7916 Cutter blade 7917 Fan 7933 Lower bearing screws (3) 7950 Brace screws (4) 8817 Upper half handle (button side) 9002 Safety switch 90051 Rotor 115 V 9008.11 Rotor 230 V 9008.12 Pluq 9009 Cortol lever 9010 Power cord 230 V		0767
Wall bracket 0881 Long wall bracket 0881.L Strain relief 230 V 0950 Strain relief 115 V 0950.1 Switch (230 V / 115 V) 0965 Capacitor 0972.1 Warning label 1017 Dynamic label 1027 Label w/ serial number 230 V 1028 Label w/ serial number 230 V 1028 Label w/ serial number 230 V 1029 bearing holder + seal 1186 Emulsifying blade 7910 Cutter blade 7917 Fan 7933 Lower bearing screws (3) 7950 Brace screws (4) 9007 Rotor 115 V 9008.11 Rotor 230 V 9008.12 Plug 9009 Control lever 9011 Handle screws (4) 9012 Ball bearing ring 9025 Stator 15 V 9038 Power cord 230 V 9016 Stator screws (2) 9023 Ball bearing ring 9025		
Strain relief 230 V 0950 Strain relief 115 V 0950.1 Switch (230 V / 115 V) 0965 Capacitor 0972.1 Warning label 0107 Dynamic label 1017 Dynamic label 1027 Label w/ serial number 230 V 1028 Label w/ serial number 115 V 1029 bearing holder + seal 1186 Emulsifying blade 7910 Lower bearing assembly 7916 Cutter blade 7917 Fan 7933 Lower bearing screws (3) 7950 Brace screws (4) 8317 Upper half handle (button side) 9002 Safety switch 9007 Rotor 115 V 9008.12 Plug 9001 Power cord 230 V 9011 Handle screws (4) 9015 Stator 230 V 9012 Ball bearing ring 9023 Ball bearing ring 9023 Ball bearing ring 9023 Barces (4) 9040		0881
Strain relief 115 V 0950.1 Switch (230 V / 115 V) 0965 Capacitor 0972. Capacitor + filter 0972.1 Warning label 1017 Dynamic label 1027 Label w/ serial number 230 V 1028 Label w/ serial number 115 V 1029 bearing holder + seal 1186 Emulsifying blade 7910 Lower bearing assembly 7916 Cutter blade 7917 Fan 7933 Lower bearing screws (3) 7950 Brace screws (4) 8317 Upper half handle (button side) 9002 Safety switch 90051 Locking switch 9007 Rotor 115 V 9008.12 Pluq 9009 Control lever 9010 Power cord 230 V 9014 Motor housing brush holder 9015 Stator 230 V 9016 Stator 230 V 9023 Ball bearing ring 9022 Braces (4) 9026 <td>Long wall bracket</td> <td>0881.L</td>	Long wall bracket	0881.L
Switch (230 V / 115 V) 0965 Capacitor 0972 Capacitor + filter 0972.1 Warning label 1017 Dynamic label 1017 Label W/ serial number 230 V 1028 Label W/ serial number 115 V 1029 bearing holder + seal 1186 Emulsifying blade 7910 Lower bearing assembly 7916 Cutter blade 7917 Fan 7933 Lower bearing screws (3) 7950 Brace screws (4) 8317 Upper half handle (button side) 9002 Safety switch 9005 Locking switch 9007 Rotor 115 V 9008.11 Rotor 230 V 9008.12 Pluq 9009 Control lever 9010 Power cord 230 V 9018 Stator 30 V 9015 Stator 30 V 9016 Stator screws (2) 9023 Ball bearing ring 9025 Braces (4) 9026 <	Strain relief 230 V	0950
Capacitor0972Capacitor + filter0972.1Warning label1017Dynamic label1027Label w/ serial number 230 V1028Label w/ serial number 115 V1029bearing holder + seal1186Emulsifying blade7910Lower bearing assembly7916Cutter blade7917Fan7933Lower bearing screws (3)7950Brace screws (4)8317Upper half handle (button side)9002Safety switch9007Locking switch9007Rotor 115 V9008.11Rotor 230 V9008.12Pluq9009Control lever9010Power cord 230 V9014Motor housing brush holder9015Stator 230 V9023Ball bearing ring9025Braces (4)9026Stator 115 V9038Power cord (Australian)9066Stator 115 V9038Power cord (Australian)9063Power cord (UK)9067Complete handle w/ power cord 230 V9010Cambon brush wires 230 V9040Carbon brush wires 230 V90101Half handle, label side (115V)9101.1Speed control knob9112Complete handle w/ power cord 230 V9101Half handle, label side (115V)9101.1Speed control knob9112Complete foot assembly9130Fitted shaft9131Carbon brush wires 115 V9143	Strain relief 115 V	0950.1
Capacitor + filter 0972.1 Warning label 1017 Dynamic label 1027 Label w/ serial number 230 V 1028 Label w/ serial number 115 V 1029 bearing holder + seal 1186 Emulsifying blade 7910 Lower bearing assembly 7917 Fan 7933 Lower bearing screws (3) 7950 Brace screws (4) 8317 Upper half handle (button side) 9002 Safety switch 9005 Locking switch 9007 Rotor 115 V 9008.11 Rotor 230 V 9008 Plug 9009 Control lever 9010 Power cord 230 V 9011 Handle screws (4) 9012 Stator screws (2) 9023 Bal bearing ring 9025 Braces (4) 9016 Stator screws (2) 9028 Power cord 115 V 9048 Power cord 115 V 9043 Power cord (Australian) 9066 <td>Switch (230 V / 115 V)</td> <td>0965</td>	Switch (230 V / 115 V)	0965
Capacitor + filter 0972.1 Warning label 1017 Dynamic label 1027 Label w/ serial number 230 V 1028 Label w/ serial number 115 V 1029 bearing holder + seal 1186 Emulsifying blade 7910 Lower bearing assembly 7917 Fan 7933 Lower bearing screws (3) 7950 Brace screws (4) 8317 Upper half handle (button side) 9002 Safety switch 9005 Locking switch 9007 Rotor 115 V 9008.11 Rotor 230 V 9008 Plug 9009 Control lever 9010 Power cord 230 V 9011 Handle screws (4) 9012 Stator screws (2) 9023 Bal bearing ring 9025 Braces (4) 9016 Stator screws (2) 9028 Power cord 115 V 9048 Power cord 115 V 9043 Power cord (Australian) 9066 <td>Capacitor</td> <td>0972</td>	Capacitor	0972
Warning label1017Dynamic label1027Label w/ serial number 230 V1028Label w/ serial number 115 V1029bearing holder + seal1186Emulsifying blade7910Lower bearing assembly7916Cutter blade7917Fan7933Lower bearing screws (3)7950Brace screws (4)8317Upper half handle (button side)9002Safety switch9005Locking switch9007Rotor 115 V9008.11Rotor 230 V9008.12Pluq9009Control lever9010Power cord 230 V9014Motor housing brush holder9015Stator 230 V9015Stator 230 V9016Plug9025Baraces (4)9025Barces (4)9025Barces (4)9026Stator 115 V9038Power cord 115 V9038Power cord 115 V9040Carbon brush wires 230 V9043Power cord (Australian)9066Power cord (UK)9067Complete handle w/ power cord 230 V9100Complete handle w/ power cord 230 V9101Half handle, label side (130V)9111Speed control knob9112Complete foot assembly9129Foot assembly w/ bearing assembly9130Fitted shaft9131Carbon brush wires 115 V9143Shaft, lower bearing & cutter assembly9143Shaft	Capacitor + filter	
Label w/ serial number 230 V1028Label w/ serial number 115 V1029bearing holder + seal1186Emulsifying blade7910Lower bearing assembly7916Cutter blade7917Fan7933Lower bearing screws (3)7950Brace screws (4)8317Upper half handle (button side)9002Safety switch9005Locking switch9007Rotor 115 V9008.11Rotor 230 V9008.12Pluq9009Control lever9011Handle screws (4)9014Motor housing brush holder9015Stator 230 V9016Stator screws (2)9023Ball bearing ring9025Braces (4)9040Carbon brush wires 230 V9043Power cord (UK)9067Complete handle w/ power cord 230 V9043Power cord (UK)9067Complete handle w/ power cord 230 V9010Half handle, label side (230V)9101Half handle, label side (115V)9100.1Half handle, label side (230V)9101Half handle, label side (115V)9101.1Speed control knob9112Foot assembly9129Foot assembly9130Fitted shaft9131Carbon brush wires 115 V9143Shaft, lower bearing & cutter assembly9130Fitted shaft9131Carbon brush wires 115 V9143Shaft, lower bearing & cutter assembly <td< td=""><td></td><td>1017</td></td<>		1017
Label w/ serial number 115 V 1029 bearing holder + seal 1186 Emulsifying blade 7910 Lower bearing assembly 7916 Cutter blade 7917 Fan 7933 Lower bearing screws (3) 7950 Brace screws (4) 8317 Upper half handle (button side) 9002 Safety switch 9005 Locking switch 9005 Rotor 115 V 9008.12 Pluq 9009 Control lever 9010 Power cord 230 V 9011 Handle screws (4) 9014 Motor housing brush holder 9015 Stator screws (2) 9023 Ball bearing ring 9025 Braces (4) 9040 Carbon brush wires 230 V 9043 Power cord (UK) 9067 Complete handle w/ power cord 230 V 90101 Half handle, label side (115V) 9100.1 Half handle, label side (230V) 9100.1 Half handle, label side (215V) 9101.1		1027
bearing holder + seal1186Emulsifying blade7910Lower bearing assembly7916Cutter blade7917Fan7933Lower bearing screws (3)7950Brace screws (4)8317Upper half handle (button side)9002Safety switch9005Locking switch9007Rotor 115 V9008.11Rotor 230 V9008.12Plug9009Control lever9010Power cord 230 V9011Handle screws (4)9014Motor housing brush holder9015Stator 230 V9016Stator 230 V9016Stator 230 V9023Ball bearing ring9025Braces (4)9026Stator 115 V9038Power cord 115 V9040Carbon brush wires 230 V9043Power cord (UK)9067Complete handle w/ power cord 230 V9043Power cord (UK)9067Complete handle w/ power cord 115 V9100.1Half handle, label side (230V)9101.1Speed control knob9112Complete foot assembly9129Foot assembly w/ bearing assembly9130Fitted shaft9131Carbon brush wires 115 V9143Shaft, lower bearing & cutter assembly9143Shaft, lower bearing & cutter assembly9143	Label w/ serial number 230 V	1028
Emulsifying blade7910Lower bearing assembly7916Cutter blade7917Fan7933Lower bearing screws (3)7950Brace screws (4)8317Upper half handle (button side)9002Safety switch9005Locking switch9007Rotor 115 V9008.11Rotor 230 V9008.12Plug9009Control lever9010Power cord 230 V9011Handle screws (4)9014Motor housing brush holder9015Stator 230 V9016Stator screws (2)9023Ball bearing ring9025Braces (4)9043Power cord 115 V9040Carbon brush wires 230 V9043Power cord (UK)9067Complete handle w/ power cord 115 V9100.1Half handle, label side (230V)9101.1Speed control knob9112Complete foot assembly9129Foot assembly w/ bearing assembly9130Fitted shaft9131Carbon brush wires 115 V9143Shaft, lower bearing & cutter assembly9164	Label w/ serial number 115 V	1029
Lower bearing assembly7916Cutter blade7917Fan7933Lower bearing screws (3)7950Brace screws (4)8317Upper half handle (button side)9002Safety switch9005Locking switch9007Rotor 115 V9008.11Rotor 230 V9008Plug9009Control lever9010Power cord 230 V9011Handle screws (4)9014Motor housing brush holder9015Stator 230 V9016Stator 230 V9016Stator screws (2)9023Ball bearing ring9025Braces (4)9040Carbon brush wires 230 V9043Power cord (LK)9066Power cord (UK)9067Complete handle w/ power cord 230 V9100.1Half handle, label side (230V)9101.1Speed control knob9112Complete foot assembly9129Foot assembly w/ bearing assembly9130Fitted shaft9131Carbon brush wires 115 V9143Shaft, lower bearing & cutter assembly9164	bearing holder + seal	1186
Lower bearing assembly7916Cutter blade7917Fan7933Lower bearing screws (3)7950Brace screws (4)8317Upper half handle (button side)9002Safety switch9005Locking switch9007Rotor 115 V9008.11Rotor 230 V9008Pluq9009Control lever9010Power cord 230 V9011Handle screws (4)9014Motor housing brush holder9015Stator 230 V9016Stator screws (2)9023Ball bearing ring9025Braces (4)9040Carbon brush wires 230 V9040Carbon brush wires 230 V9043Power cord (UK)9067Complete handle w/ power cord 230 V9100.1Half handle, label side (230V)9101.1Speed control knob9112Complete foot assembly9129Foot assembly w/ bearing assembly9130Fitted shaft9131Carbon brush wires 115 V9143Shaft, lower bearing & cutter assembly9164	Emulsifying blade	7910
Cutter blade7917Fan7933Lower bearing screws (3)7950Brace screws (4)8317Upper half handle (button side)9002Safety switch9005Locking switch9007Rotor 115 V9008.11Rotor 230 V9008Plug9009Control lever9010Power cord 230 V9011Handle screws (4)9014Motor housing brush holder9015Stator 230 V9016Stator 230 V9016Stator screws (2)9023Ball bearing ring9025Braces (4)9040Carbon brush wires 230 V9043Power cord 115 V9043Power cord (UK)9067Complete handle w/ power cord 230 V9100.1Half handle, label side (230V)9101.1Speed control knob9112Complete foot assembly9129Foot assembly w/ bearing assembly9130Fitted shaft9131Carbon brush wires 115 V9143Shaft, lower bearing & cutter assembly9164		7916
Lower bearing screws (3)7950Brace screws (4)8317Upper half handle (button side)9002Safety switch9005Locking switch9007Rotor 115 V9008.11Rotor 230 V9008.12Plug9009Control lever9010Power cord 230 V9011Handle screws (4)9014Motor housing brush holder9015Stator 230 V9016Stator 230 V9025Ball bearing ring9025Barces (4)9026Stator 115 V9038Power cord 115 V9040Carbon brush wires 230 V9043Power cord (UK)9067Complete handle w/ power cord 230 V9100.1Half handle, label side (230V)9101.1Speed control knob9112Complete foot assembly9129Foot assembly w/ bearing assembly9130Fitted shaft9131Carbon brush wires 115 V9143Shaft, lower bearing & cutter assembly9164	Cutter blade	7917
Lower bearing screws (3)7950Brace screws (4)8317Upper half handle (button side)9002Safety switch9005Locking switch9007Rotor 115 V9008.11Rotor 230 V9008.12Plug9009Control lever9010Power cord 230 V9011Handle screws (4)9014Motor housing brush holder9015Stator 230 V9016Stator 230 V9025Ball bearing ring9025Barces (4)9026Stator 115 V9038Power cord 115 V9040Carbon brush wires 230 V9043Power cord (UK)9067Complete handle w/ power cord 230 V9100.1Half handle, label side (230V)9101.1Speed control knob9112Complete foot assembly9129Foot assembly w/ bearing assembly9130Fitted shaft9131Carbon brush wires 115 V9143Shaft, lower bearing & cutter assembly9164	Fan	7933
Brace screws (4)8317Upper half handle (button side)9002Safety switch9005Locking switch9007Rotor 115 V9008.11Rotor 230 V9008.12Plug9009Control lever9010Power cord 230 V9011Handle screws (4)9014Motor housing brush holder9015Stator 230 V9016Stator screws (2)9023Ball bearing ring9025Braces (4)9040Carbon brush wires 230 V9043Power cord (Australian)9066Power cord (UK)9067Complete handle w/ power cord 230 V9100.1Half handle, label side (115V)9101.1Speed control knob9112Complete foot assembly9129Foot assembly w/ bearing assembly9130Fitted shaft9131Carbon brush wires 115 V9143Shaft, lower bearing & cutter assembly9164	Lower bearing screws (3)	
Upper half handle (button side)9002Safety switch9005Locking switch9007Rotor 115 V9008.11Rotor 230 V9008.12Plug9009Control lever9010Power cord 230 V9011Handle screws (4)9014Motor housing brush holder9015Stator 230 V9016Stator screws (2)9023Ball bearing ring9025Braces (4)9040Carbon brush wires 230 V9043Power cord (Australian)9066Power cord (UK)9067Complete handle w/ power cord 230 V9100.1Half handle, label side (230V)9101.1Speed control knob9112Complete foot assembly9129Foot assembly w/ bearing assembly9130Fitted shaft9131Carbon brush wires 115 V9143Shaft, lower bearing & cutter assembly9164		8317
Safety switch9005Locking switch9007Rotor 115 V9008.11Rotor 230 V9008.12Plug9009Control lever9010Power cord 230 V9011Handle screws (4)9014Motor housing brush holder9015Stator 230 V9016Stator 230 V9016Stator screws (2)9023Ball bearing ring9025Braces (4)9026Stator 115 V9038Power cord 115 V9040Carbon brush wires 230 V9043Power cord (Australian)9066Power cord (UK)9067Complete handle w/ power cord 230 V9100.1Half handle, label side (230V)9101.1Speed control knob9112Complete foot assembly9129Foot assembly w/ bearing assembly9130Fitted shaft9131Carbon brush wires 115 V9143Shaft, lower bearing & cutter assembly9164		9002
Locking switch9007Rotor 115 V9008.11Rotor 230 V9009Control lever9010Power cord 230 V9011Handle screws (4)9014Motor housing brush holder9015Stator 230 V9016Stator 230 V9016Stator screws (2)9023Ball bearing ring9025Braces (4)9026Stator 115 V9038Power cord 115 V9040Carbon brush wires 230 V9043Power cord (Australian)9066Power cord (UK)9067Complete handle w/ power cord 115 V9100.1Half handle, label side (230V)9101.1Speed control knob9112Complete foot assembly9129Foot assembly w/ bearing assembly9130Fitted shaft9131Carbon brush wires 115 V9143Shaft, lower bearing & cutter assembly9164		9005
Rotor 115 V 9008.11 Rotor 230 V 9008.12 Plug 9009 Control lever 9010 Power cord 230 V 9011 Handle screws (4) 9014 Motor housing brush holder 9015 Stator 230 V 9016 Stator 230 V 9016 Stator screws (2) 9023 Ball bearing ring 9025 Braces (4) 9026 Stator 115 V 9038 Power cord 115 V 9040 Carbon brush wires 230 V 9043 Power cord (Australian) 9066 Power cord (UK) 9067 Complete handle w/ power cord 230 V 9100 Complete handle w/ power cord 115 V 9100.1 Half handle, label side (230V) 9101.1 Speed control knob 9112 Complete foot assembly 9129 Foot assembly w/ bearing assembly 9130 Fitted shaft 9131 Carbon brush wires 115 V 9143 Shaft, lower bearing & cutter assembly 9164 <td></td> <td></td>		
Plug9009Control lever9010Power cord 230 V9011Handle screws (4)9014Motor housing brush holder9015Stator 230 V9016Stator 230 V9023Ball bearing ring9025Braces (4)9026Stator 115 V9038Power cord 115 V9040Carbon brush wires 230 V9043Power cord (Australian)9066Power cord (UK)9067Complete handle w/ power cord 115 V9100.1Half handle, label side (230V)9101.1Speed control knob9112Complete foot assembly9129Foot assembly w/ bearing assembly9130Fitted shaft9131Carbon brush wires 115 V9143Shaft, lower bearing & cutter assembly9164		9008.11
Control lever9010Power cord 230 V9011Handle screws (4)9014Motor housing brush holder9015Stator 230 V9016Stator 230 V9023Ball bearing ring9025Braces (4)9026Stator 115 V9038Power cord 115 V9040Carbon brush wires 230 V9043Power cord (Australian)9066Power cord (UK)9067Complete handle w/ power cord 115 V9100.1Half handle, label side (230V)9101.1Speed control knob9112Complete foot assembly9129Foot assembly w/ bearing assembly9130Fitted shaft9131Carbon brush wires 115 V9143Shaft, lower bearing & cutter assembly9164	Rotor 230 V	9008.12
Control lever9010Power cord 230 V9011Handle screws (4)9014Motor housing brush holder9015Stator 230 V9016Stator 230 V9023Ball bearing ring9025Braces (4)9026Stator 115 V9038Power cord 115 V9040Carbon brush wires 230 V9043Power cord (Australian)9066Power cord (UK)9067Complete handle w/ power cord 115 V9100.1Half handle, label side (230V)9101.1Speed control knob9112Complete foot assembly9129Foot assembly w/ bearing assembly9130Fitted shaft9131Carbon brush wires 115 V9143Shaft, lower bearing & cutter assembly9164	Plug	9009
Handle screws (4)9014Motor housing brush holder9015Stator 230 V9016Stator screws (2)9023Ball bearing ring9025Braces (4)9026Stator 115 V9038Power cord 115 V9040Carbon brush wires 230 V9043Power cord (Australian)9066Power cord (UK)9067Complete handle w/ power cord 230 V9100.1Half handle, label side (230V)9101.1Speed control knob9112Complete foot assembly9129Foot assembly w/ bearing assembly9130Fitted shaft9131Carbon brush wires 115 V9164		9010
Motor housing brush holder9015Stator 230 V9016Stator screws (2)9023Ball bearing ring9025Braces (4)9026Stator 115 V9038Power cord 115 V9040Carbon brush wires 230 V9043Power cord (Australian)9066Power cord (UK)9067Complete handle w/ power cord 230 V9100.1Half handle, label side (230V)9101.1Speed control knob9112Complete foot assembly9129Foot assembly w/ bearing assembly9130Fitted shaft9131Carbon brush wires 115 V9164	Power cord 230 V	9011
Stator 230 V9016Stator screws (2)9023Ball bearing ring9025Braces (4)9026Stator 115 V9038Power cord 115 V9040Carbon brush wires 230 V9043Power cord (Australian)9066Power cord (UK)9067Complete handle w/ power cord 230 V9100.1Half handle, label side (230V)9101.1Speed control knob9112Complete foot assembly9129Foot assembly w/ bearing assembly9130Fitted shaft9131Carbon brush wires 115 V9164	Handle screws (4)	9014
Stator 230 V9016Stator screws (2)9023Ball bearing ring9025Braces (4)9026Stator 115 V9038Power cord 115 V9040Carbon brush wires 230 V9043Power cord (Australian)9066Power cord (UK)9067Complete handle w/ power cord 230 V9100.1Half handle, label side (230V)9101.1Speed control knob9112Complete foot assembly9129Foot assembly w/ bearing assembly9130Fitted shaft9131Carbon brush wires 115 V9164	Motor housing brush holder	9015
Ball bearing ring 9025 Braces (4) 9026 Stator 115 V 9038 Power cord 115 V 9040 Carbon brush wires 230 V 9043 Power cord (Australian) 9066 Power cord (UK) 9067 Complete handle w/ power cord 230 V 9100 Complete handle w/ power cord 115 V 9100.1 Half handle, label side (230V) 9101.1 Speed control knob 9112 Complete foot assembly 9130 Fitted shaft 9131 Carbon brush wires 115 V 9143 Shaft, lower bearing & cutter assembly 9164		9016
Ball bearing ring 9025 Braces (4) 9026 Stator 115 V 9038 Power cord 115 V 9040 Carbon brush wires 230 V 9043 Power cord (Australian) 9066 Power cord (UK) 9067 Complete handle w/ power cord 230 V 9100 Complete handle w/ power cord 115 V 9100.1 Half handle, label side (230V) 9101.1 Speed control knob 9112 Complete foot assembly 9130 Fitted shaft 9131 Carbon brush wires 115 V 9143 Shaft, lower bearing & cutter assembly 9164	Stator screws (2)	9023
Braces (4) 9026 Stator 115 V 9038 Power cord 115 V 9040 Carbon brush wires 230 V 9043 Power cord (Australian) 9066 Power cord (UK) 9067 Complete handle w/ power cord 230 V 9100 Complete handle w/ power cord 115 V 9100.1 Half handle, label side (230V) 9101 Half handle, label side (115V) 9101.1 Speed control knob 9112 Complete foot assembly 9129 Foot assembly w/ bearing assembly 9130 Fitted shaft 9131 Carbon brush wires 115 V 9143 Shaft, lower bearing & cutter assembly 9164		9025
Stator 115 V9038Power cord 115 V9040Carbon brush wires 230 V9043Power cord (Australian)9066Power cord (UK)9067Complete handle w/ power cord 230 V9100Complete handle w/ power cord 115 V9100.1Half handle, label side (230V)9101.1Speed control knob9112Complete foot assembly9129Foot assembly w/ bearing assembly9130Fitted shaft9131Carbon brush wires 115 V9164		9026
Power cord 115 V 9040 Carbon brush wires 230 V 9043 Power cord (Australian) 9066 Power cord (UK) 9067 Complete handle w/ power cord 230 V 9100 Complete handle w/ power cord 115 V 9100.1 Half handle, label side (230V) 9101 Half handle, label side (115V) 9101.1 Speed control knob 9112 Complete foot assembly 9129 Foot assembly w/ bearing assembly 9130 Fitted shaft 9131 Carbon brush wires 115 V 9143 Shaft, lower bearing & cutter assembly 9164		
Carbon brush wires 230 V9043Power cord (Australian)9066Power cord (UK)9067Complete handle w/ power cord 230 V9100Complete handle w/ power cord 115 V9100.1Half handle, label side (230V)9101Half handle, label side (115V)9101.1Speed control knob9112Complete foot assembly9129Foot assembly w/ bearing assembly9130Fitted shaft9131Carbon brush wires 115 V9164	Power cord 115 V	
Power cord (Australian)9066Power cord (UK)9067Complete handle w/ power cord 230 V9100Complete handle w/ power cord 115 V9100.1Half handle, label side (230V)9101Half handle, label side (115V)9101.1Speed control knob9112Complete foot assembly9129Foot assembly w/ bearing assembly9130Fitted shaft9131Carbon brush wires 115 V9164		
Power cord (UK) 9067 Complete handle w/ power cord 230 V 9100 Complete handle w/ power cord 115 V 9100.1 Half handle, label side (230V) 9101 Half handle, label side (115V) 9101.1 Speed control knob 9112 Complete foot assembly 9129 Foot assembly w/ bearing assembly 9130 Fitted shaft 9131 Carbon brush wires 115 V 9164		
Complete handle w/ power cord 230 V9100Complete handle w/ power cord 115 V9100.1Half handle, label side (230V)9101Half handle, label side (115V)9101.1Speed control knob9112Complete foot assembly9129Foot assembly w/ bearing assembly9130Fitted shaft9131Carbon brush wires 115 V9164		
Complete handle w/ power cord 115 V9100.1Half handle, label side (230V)9101Half handle, label side (115V)9101.1Speed control knob9112Complete foot assembly9129Foot assembly w/ bearing assembly9130Fitted shaft9131Carbon brush wires 115 V9143Shaft, lower bearing & cutter assembly9164		
Half handle, label side (230V)9101Half handle, label side (115V)9101.1Speed control knob9112Complete foot assembly9129Foot assembly w/ bearing assembly9130Fitted shaft9131Carbon brush wires 115 V9143Shaft, lower bearing & cutter assembly9164		
Half handle, label side (115V) 9101.1 Speed control knob 9112 Complete foot assembly 9129 Foot assembly w/ bearing assembly 9130 Fitted shaft 9131 Carbon brush wires 115 V 9143 Shaft, lower bearing & cutter assembly 9164		
Speed control knob 9112 Complete foot assembly 9129 Foot assembly w/ bearing assembly 9130 Fitted shaft 9131 Carbon brush wires 115 V 9143 Shaft, lower bearing & cutter assembly 9164		
Complete foot assembly 9129 Foot assembly w/ bearing assembly 9130 Fitted shaft 9131 Carbon brush wires 115 V 9143 Shaft, lower bearing & cutter assembly 9164		
Foot assembly w/ bearing assembly 9130 Fitted shaft 9131 Carbon brush wires 115 V 9143 Shaft, lower bearing & cutter assembly 9164		
Fitted shaft 9131 Carbon brush wires 115 V 9143 Shaft, lower bearing & cutter assembly 9164		
Carbon brush wires 115 V 9143 Shaft, lower bearing & cutter assembly 9164		
Shaft, lower bearing & cutter assembly 9164		
	Lower bearing screws (3)	9902

